# **Operating Manual**

Product:

Combination Display Case SWITCH



Combination display case for dual temperature.

# **Operating and Maintenance instructions**

Please read this manual carefully before you start to operate your combination display case. Following these instructions helps you to ensure having a fully functional unit at all times.



Warranty claims can only be forwarded if all instructions are strictly followed!

# **Operation and maintenance**

1	Introduction	2
	Welcome	2
	Fundamental Safety Notes	2
	Warranty and Liabilities	2
	Symbols and Notes	3
	Validity	3
2	Purpose of use	4
3	Proper use of the unit	4
4	Improper use of the unit	4
	Obligation of the Manager	4
	Obligation of the Personnel	4
	Possible Risk	4
5	Safety Notes	5
6	Fundamental operating notes	6
	Switching on the appliance – Cold Mode	6
	Setting the temperature – Cold Mode	6
	Manual defrosting – Cold Mode	6
	Lighting – Cold Mode	6
	Switching on the appliance – Hot Mode	7
	Setting the temperature – Hot Mode	7
	Lighting – Hot Mode	7
7	Functional description	8
	Chilled display case	8
	Heated display case	9
8	Cleaning and care	10
	General Recommendations	10
	Detergents	11
9	Trouble shooting	12
10	Dangers	14
11	Maintenance	14
12	Wiring diagram	15
13	Declaration of Conformity	16

### **OPERATING AND MAINTENANCE**

### 1. Introduction

### 1.1. Welcome

With the purchase of this new Combination of chilled and heated display case you have decided on a product that combines the highest technical demands with practical service comfort. We recommend that you read these operating and maintenance instructions carefully in order to become familiar with the product quickly.

With the proper treatment you will enjoy this appliance for a long time. Please keep these operating and maintenance instructions to consult in case any maintenance and repairs are needed.

We wish you successful business and much pleasure with this appliance.

### 1.2. Fundamental Safety Notes



The installation and any technical modifications are only to be carried out by specialists! This is especially valid for any electrical installation and mechanical work.

Any modification is to be authorized by the manufacturer!

- Those covers bearing a warning may only be opened by specialists!
- The bottom and back panels are not to be cleaned by water jet.
- Protective covers and devices may not be removed due to risk of injury!
- The control system may only be opened by an expert.
- The surrounding temperature may not exceed 75°F; the relative humidity may not exceed 55% over a long period of time.
- Due to risk of injury, sharp objects are not to be stored loosely in the heated unit.
- Any glass parts are to be treated with the necessary care in order to avoid injuries resulting from broken glass.
- Components and operating equipment may only be replaced by original parts.

### 1.3. Warranty and Liabilities

Fundamentally, our "General terms of sale and delivery" are valid. These are known to the operator upon the signing of the contract at the latest. Claims of warranty and liability for damage to persons and property are not possible, if they result from one or several of the following causes:

- Improper use of the unit.
- Improper assembling, starting up, operating and servicing of the unit.
- Operating the unit with defective safety devices or safety devices which have not been installed properly and are not in working condition.
- Disregard of the instructions in the operating manual concerning transportation storage, installation, start-up, operation, maintenance and assembling of the unit.
- Unauthorized mechanical or electrical changes to the unit.
- Insufficient maintenance of wear and tear parts.
- Unauthorized repair.
- Extreme environmental concern, fire, explosions etc.

### 1.4. Symbols and Notes



This symbol points to important references for the proper use of the unit.

Not paying attention to these references can lead to disturbances at the unit or in the environment!



This symbol means a possible or directly threatening danger to the life and health of persons and/or a possibly dangerous situation.


Ignoring these references may result in dire consequences for your health and/or can lead to property damages!



This symbol points to operation tips and especially useful information. *Helps you to use all functions on your unit optimally.* 

### 1.5. Validity

These operating instructions are valid for the models:



### 2. Purpose of use

The <u>refrigerated part</u> of the display cases is suitable for the refrigeration and presentation of foodstuffs and drinks at temperatures ranging from 37°F to 40°F.

The <u>heated part</u> of the display cases have been specially developed for keeping temperature and presentation of foodstuffs at temperatures ranging from 150°F to 185°F.

This unit is not suitable for chilling or cooking. Any products to be presented have to be chilled or heated to the temperature required before being placed in the unit.



Do not fill with cold foods in the heated part; and no hot foods in the chilled part! Before the display cases are filled, please wait until the desired temperature has been reached.

### 3. Proper use the unit

The combination display cases conform to current state-of-the-art technology, are constructed in accordance with the recognized safety regulations and are reliable.

The appliance may only be operated in a technically acceptable condition and in accordance with all regulations, safety regulations and conscious of risks with regard to the operating instructions! Any other uses beyond those intended are to be considered as not being in compliance with the regulations. The manufacturer/supplier is not liable for any damages resulting from such actions. The user bears the entire risk.

Use in accordance with the regulations includes observance of the mounting and operating instructions and keeping with the inspection and maintenance regulations.

After cleaning the appliance is to be checked for any loose connections, shears and damages. Any defects found should be repaired. The appliance is not to be used for non-operating purposes. Any changes to the appliance are to be made solely by the manufacturer!

### 4. Improper use of the unit

The refrigerated display cases are not suitable for chilling foods. No foodstuffs having a higher temperature than indicated are to be filled into the display. Safe operation at temperatures of less than 35°F is not possible.

The ventilation slots in the front and back panels of the display area may not be covered as doing so will result in cutting off air circulation and preventing the cooling function.

### 4.1 Obligation of the Manager

The Manager is obliged to only let personnel work with the unit who:

- are familiar with the fundamental regulations of work safety and accident avoiding and who have been instructed how to operate the unit.
- read and understood the chapter about safety and warning notes and have confirmed this with their signature.

The safe conscious operation of the personnel has to be examined regularly.

### 4.2. Obligation of the Personnel

All individuals who are authorized to work with the unit are obliged to:

- pay attention to the fundamental regulations of work safety and accident avoiding,
- read the chapter on work safety and warning notes in this manual and to confirm through their signature that they have understood these, before actually operating the unit.

### 4.3. Possible Risks

Hot cabinets are built state of the art and in acknowledgement of all safety related rules. Nevertheless is it possible that physical danger occurs for the user and/or third parties. The unit is to be used only:

- for the due use.
- in safety related flawless condition.

Disturbances which can be a threat to safety are to be eliminated immediately.

## 5. Safety notes

All safety regulations were followed during manufacturing, particularly the VDE regulations (Association for Electrical, Electronic & Information Technologies) and international CEE regulations. The appliance was subject to a comprehensive final check at the plant.

# 6. Fundamental operating notes

### 6.1. Switching on the appliance - COLD MODE

The Display case is switched on and off by pressing the STANDBY button (5).

Above the buttons there is a digital display of the cooling regulator. This field shows the medium temperature and any errors.

Before filling the display cases with food, please wait until the desired temperature has been reached.



Key 1	UP - button	Defrosting can be started any time by pressing the UP-key for 3 seconds		
Key 2	DOWN - button	The DOWN key, among other functions, can acknowledge an alarm		
Key 3	LIGHTING	Switch for lighting		
Key 4	SET - button	While SET key is pressed, the setpoint is indicated		
Key 5	STANBY - button	With this key the controller is switched to standby mode.  Pressing the key a second time, restarts the unit		

### 6.2. <u>Setting the temperature</u> - **COLD MODE**

The interior temperature is regulated by an electric temperature regulator. This is located underneath the refrigerated well and is easily accessible.

On the service side the refrigerated display case is set at a temperature of 5°C. Your desired temperature can be set by holding down the SET button (4) and simultaneously pressing UP - button (1) for higher temperatures or DOWN - button (2) for lower temperatures.



# The desired value can only be set within a certain range in order to prevent any operating errors.

After adjusting the temperature setting, it takes some time before the desired temperature has been reached. Please check the interior temperature an hour afterwards with an exact thermometer and adjust the thermostat if needed.

Depending on the surrounding temperature and humidity, the interior temperature is not to be set too low as this could lead to icing on exposed areas of the cooling element. This will interfere with the cooling performance and with the continuous defrosting which has been set by your specialized dealer for a certain interval.

### 6.3. Manual defrosting - COLD MODE

Defrosting can be started any time by pressing the UP - button for 3 seconds. During the process of defrosting the respective LED is illuminated. The LED flashes if defrosting is requested, but may not be started yet due to interlock conditions.

### 6.4. <u>Lighting</u> - **COLD MODE**

Lighting of the Display case is connected to the control unit and is then switched on and off by pressing button (3).

### 6.5. Switching on the appliance - HOT MODE



To Start the HOT mode, you have to switch the toggle switch in position "2"

The temperature control of the Hot mode is switched on and controlled by a thermostat (black coloured control dial)

The temperature and light of the warm bridge is switched on an controlled by a dimmer (silver coloured control dial)

### 6.6. <u>Setting the temperature</u> - **HOT MODE**

The interior temperature is regulated by a thermostat, desired temperature can be set by turning the black coloured control dial.

After adjusting the temperature setting, it takes some time before the desired temperature has been reached. Please check the interior temperature an hour afterwards with an exact thermometer and adjust the thermostat if needed.

The interior temperature is regulated by a thermostat. This is located on the right hand side of the electronics box and is easily accessible.

The desired temperature can be set from 1 up to 12 (100%), increasing temperature by turning the dial clockwise



The desired value can only be set within a certain range in order to prevent any operating errors.

After adjusting the temperature setting, it takes some time before the desired temperature has been reached. Please check the interior temperature an hour afterwards with an exact thermometer and adjust the thermostat if needed.

### 6.7. <u>Lighting</u> - <u>HOT MODE</u>

Lighting of the heated display case is connected to the electronics box and is then switched on and off by pressing the green switch (1) beside the temperature control unit. The case is illuminated by special fluorescent lighting fixtures.

<u>Caution</u>: Use only original fluorescent lamps supplied from the manufacturer. These lamps are heat resistant and coated to prevent splintering.

### 7. Functional description

This combination display case is separated into 3 different temperature zones, - two refrigerated and one hot display area with its own control unit.

Each section is switched on / off by pressing the STANDBY button on its control unit.

### **COOLING MODE**

### 7.1. Load Display Case


Load the display case with pre-chilled product from the rear doors. You can place the goods on the glass shelves and on the base trays. BRILLANT models; open at front; have a deep well with height adjustable base trays.

The display case is designed to maintain the temperature of pre-chilled product.

This refrigerated unit is not a refrigerator, and consequently, if warm product is introduced, there could be a considerable delay before the operating temperature falls to the normal operating level.

### 7.2. <u>Loading Restrictions</u>

- It is important to leave adequate free space for the refrigerated air to circulate within the display case.
- Product should be kept clear of the shaded areas, shown in the picture.
- A minimum clearance of 40 mm should be maintained below the light fittings and air baffle.
- The air louvers at the front and rear of the display case must not covered at all.



The presented goods are refrigerated with cold air.

This air curtain is forced by fans which suck the air via air louvers at the front (1) into the Evaporator (2).

In this area below the base tray the air is chilled and blown up through the louvers at the rear (3) into the display case.

All these components are designed to have an even distribution of chilled air in the whole display case to guarantee constant temperature.




It is important to keep all cabinet doors closed. If the doors are not fully closed, an even temperature will not be maintained within the display case.

### **HOT MODE**

The quartz infrared heater on the top is for even heating, guarantees the required core temperature. The infrared heat reaches the core of the goods, heating the inside, so you don't burn the surface of the product and don't dry them.

The base and the shelves are made of CERAN glass with heated plate on the bottom and stainless steel frame around. This heating plate is regulated together with the infrared heaters above.

To optimize the product presentation, the display case is equipped with effective fluorescent lighting fixtures, to give an appetizing appearance of the goods.



The maximum displaying time depends on the kind of product and the products starting temperature. It might be limited by national or local regulations. Never equip the cabinet with cold or deep frozen products.



Don't fill up to many products and leave a distance to the heating elements above. Otherwise the goods can get dry or burn.



It is important to keep all cabinet doors closed. If the doors are not fully closed, an even temperature will not be maintained within the display case.

### 8. Cleaning and care

Following is some advice on maintenance, care, trouble shooting and service for your combination display cases. The interior and the outside of the unit have to be cleaned every day in accordance with hygiene regulations. Only then can you guarantee optimal presentation of the goods.



### **CAUTION:**

Before you start to clean and care switch off the appliance and disconnect it from the mains!

For cleaning purposes the unit must be turned off. Therefore, the best time for cleaning is at the end of your working day. Wait till the heated part is cooled down – Danger for burning!

### 8.1. General Recommendations

- The unit has to be cleaned daily.
- Wear acid-proof gloves while cleaning the parts to prevent skin irritations.
- After cleaning with special cleaners you have to wash all parts with clear water and dry them so that there is no cleaner residue on these parts.
- It is absolutely necessary to bear some fundamental things in mind to keep this stainless steel unit working and to maintain its long life:
  - always keep the stainless steel surface clean.
  - make certain there is always enough fresh air on the surface.
  - never let the surface come into contact with rusty material.

### 8.2. Detergents



### Use the following detergents!

- Lukewarm soap water
  - Use lukewarm soap water for all surfaces that are in direct contact with the goods.
- Glass-cleaner
  - Removes grease from glass-surfaces. You can lift the glass panels for easy cleaning of the glass and the surfaces underneath.
- Stainless-steel-cleaner
  - The stainless steel surfaces should be cleaned with a stainless-steel-cleaner only.
- Lamps
  - The lamps are to be cleaned with soft paper or cloth only.
- Drawers, GN pans
  - Easily removable without tools for separate cleaning.
  - Use brushes with plastic or natural bristles for cleaning.



### Avoid the following detergents!

- Do not use acid, bleaching or chlorine cleaners.
- Never use high-pressure, water pressure or steam jet cleaning machines.
- Do not use inflammable detergents.
- Never use sharp-edged or metallic tools like Steel-wool or Scrubbing cleanser for cleaning.

### 8.3. Special cleaning hints

• Remove the inner tub (1) (base trays, air baffle on the side and the well) from the display case and tilt the evaporator (2), then sway the lock to the left. Now the evaporator is fixed and you can clean the interior. First of all remove crass dirt to avoid a blockage of the drain.

Picture 1





- The evaporator and the interior (3) have to be cleaned with lukewarm soap water. Fan in low voltage, which allows for danger-free rinsing of the evaporators and the fan with a hand spray. Always dry the interior after cleaning. After cleaning lift the evaporator, remove the lock and drop the evaporator, drop in the inner well (1), position the air baffle with the hanging track and drop in the base tray.
- Never clean the rear or the bottom of the tub with a water hose or a scrubber. Avoid flowing water near this areas.
- All other surfaces can be cleaned with soft detergents or water.
- If the condenser is contaminated it has to be cleaned with a broom or a vacuum cleaner.
- Do not close or put any objects in front of the air-inlet and air-outlet of the counter because otherwise the refrigerating power of the Condensing unit will be reduced.
- Lift-up the glass pane (4) to clean the glass and also the metal part below. To clean the front glass tilt the pane and hold it with one hand (5-6). Don't let out the front glass while cleaning otherwise the glass could break or damage the aluminium hinge due the weight.

Picture 4



Picture 5



Picture 6





### **CAUTION:**

After all cleaning has been completed the refrigeration well has to be returned to its original state in order to guarantee efficient operation!

In addition to daily cleaning, service and maintenance of the display case is required to be carried out in regular intervals by qualified specialists.

( see Chapter 11 MAINTENANCE )

# 9. Trouble shooting

If your combination unit does not work satisfactorily we would like to give a first help with the following checklist. Only after checking these points you should contact your customer service:

### **Checklist for your cooled display:**

If the refrigerated appliance is not working at all please check whether:

•	The power supply is interrupted	Self-checking
•	A fuse has blown	Self-checking
•	The plug is firmly in the socket	Self-checking
•	Power has been switched on	Self-checking
•	The electronic has been properly set	Self-checking

### The refrigeration equipment is working, but incorrect:

### The products are too warm or too cold:

	. · · · · · · · · · · · · · · · · · · ·	
•	Is the condenser clean?	Self-checking
•	Is the surrounding temperature too high?	Self-checking
•	Is there too much food or is it too warm?	Self-checking
•	Has the evaporator not been defrosted?	Self-checking
•	The refrigerated well is subject to strong draughts	Self-checking
•	The cooling unit is malfunctioning	Customer service
•	The cooling regulator is set wrong	Customer service

### The evaporators are constantly iced up:

- Defrosting does not begin
   The ventilators are not running
   Customer service
   Customer service

### Status display and error notification - COLD MODE

Message	Cause	Error elimination
Temperature indication flashes	Refrigerating chamber temperature beyond alarm limits (parameter A1 A2)	
E0	Refrigerating chamber sensor F1	Control sensor. Controller operates
flashes	error, break or short-circuit	according to with parameter c3.
E1	Sensor F2 error,	Control sensor. At setting [c3=1] the
flashes	break or short-circuit	controller operates in timed defrosting modus (defrosting time as set in d3).
<b>EP</b> flashes	Data loss at parameter memory	Unplug the appliance. Press and hold down buttons (4) SET and (1) UP and plug the power plug back into the socket. By doing so the electronic will re-program itself.  If Error occurs again please contact customer service.

Should the options listed not be the cause of the error, please contact customer service.

### **Checklist for your heated display:**

- Is the unit wired properly and connected to the mains?
- Does the wall socket provide the required current / voltage (see the nameplate for details)?
- Does the circuit breaker work properly?
- Do all heating elements of the unit work properly?
- Are there cold or frozen food in the cabinet?
- Is the thermostat adjusted properly?
- Do all lamps work properly?
- Check lamps and dimmer for the lighting!

Should the options listed not be the cause of the error, please contact customer service.



The manufacturer is not liable for loss of goods, even if the appliance is still covered by warranty.

Therefore it's recommended to check the temperature periodically.

### 10. Dangers

### **Electrical Energy**



### CAUTION: ELECTRICALS HOCK HAZARD

DO NOT splash or pour water onto control panel or wiring

Switch the appliance off immediately upon interruptions in the electrical power supply!

Any work carried out on the electrical units or utilities may only be carried out in accordance with electrical regulations by an electrician specialist or by those being instructed and supervised by an electrician specialist.

Appliances and unit components which are subject to inspection, maintenance and repair work have to be completely disconnected and volt-free. First, check as to whether the activated parts have indeed been disconnected and are volt-free, then ground and short them out. Insulate any adjacent parts that are also energized!

### Heat Energy



### CAUTION: HOT SURFACE

Exposed surfaces can be hot to the touch and may cause burns.

When in use not only the inside is heated but also the outside of the display case can be hot to touch.

### 11. Maintenance

In order to guarantee efficient operation of the refrigerated & heated display case along with optimum presentation of the goods, the entire technological equipment has to be checked and maintained regularly.

### Service and maintenance, troubleshooting


- Prescribed adjustment, service and inspection work is to be accomplished timely by the manager or if necessary by an authorized service technician.
- The operating personal is to be informed before the beginning of the maintenance and service work.
- The unit is to be disconnected from the mains before maintaining, inspecting and repairing is performed; the main switch is to be guarded against unintended reclosing.
- Check all screw connections for tight fitting.
- After finishing maintenance check all safety devices for proper functionality.

### The following should be done

- complete cleaning of the entire heated display case
- checking the Quartz infrared heaters for functionality
- checking the halogen lamps and the dimmer
- · checking the thermostat setting
- checking the temperature of the unit
- checking the mechanical functions (glass, doors, hinges ..)
- making a security check of the unit

# 240 V / 2 ph / 60 Hz

Wiring diagram: SNACK-Line - Swicht model





# **DECLARATION of CONFORMITY**

Confirming the EC directives 73/23/EEC and 89/336/EEC

Company

# Ausseer Kälte und Edelstahltechnik GmbH

A-8984 Kainisch, Pichl 66

We herewith declare under our sole responsibility that the AKE product:

**COMBINATION DISPLAY CASE – SNACK-Line** 

types designated as: SWITCH 2-E

**SWITCH 3-E** 

which is covered by this declaration, meets all safety provision of the EC directives **73/23/EEC** amended by 93/68/EEC (Low-voltage directive) and **89/336/EEC** amended by 92/31/ECC (Electromagnetic compatibility EMC directive). These directives represent legal binding laws of the European Union for electrical equipments.

To meet all safety and sanitation EC directives we fully comply with all applicable requirements of the following international and national standards:

HD 277 S1

DIN VDE 32733, issue. 01.89

Druckbeh. V/05.89

HD 280 S1

**DIN VDE 0530** 

EN 60335-1

EN 60730-2

EN 50081-1: EN 55022

EN 50082-1: IEC 1000-4-2-LEVEL IV.

IEC 1000-4-3-5 V/m, IEC 1000-4-4-LEVEL IV

DIN IEC 255 part 1-00

DIN VDE 0435 part 201/05.83

DIN IEC 255 part 0-20

DIN VDE 0630/04.86

### **Andreas Pilz**

Managing director